

# CLEANING AND STERILIZATION PROTOCOL

## 4.5mm Tiger Cannulated Screw System



### CLEANING

Trained personnel must perform cleaning and mechanical inspection prior to sterilization. Compliance is required with the equipment manufacturer's user instructions (manual and/or machine cleaning, ultrasound treatment, etc.) and recommendations for chemical detergents. Trilliant Surgical recommends the following cleaning instructions for reusable instrumentation:

#### Recommended Automatic Cleaning Instructions:

1. Rinse with tap water to remove gross soil
2. Inject water (60mL) into cannulation to remove gross soil
3. Prepare enzymatic detergent (Enzol®) at manufacturer recommendation (1oz/gal) using lukewarm tap water and fully immerse parts
4. Use a soft bristled brush (Spectrum M16 or equivalent) and appropriately sized lumen brush to brush all surfaces
5. Use syringe to inject detergent (60mL) into cannulation
6. Allow articles to dwell in detergent bath for 1 minute
7. Remove parts from bath and rinse using reverse osmosis/deionized (RO/DI) water
8. Fill syringe with RO/DI water (60mL) and flush part cannulation, where applicable
9. Transfer parts into automated washer (STERIS® Reliance Genfore) for processing using the following parameters:

Phase	Recirculation Time	Temperature	Detergent Type and Concentration
Pre-wash 1	02:00	Cold tap water	N/A
Enzyme Wash	02:00	Hot tap water	Enzol® 1 oz/gal
Wash 1	02:00	65.5°C	Prolystica® 2X Neutral 1/8 oz/gal
Rinse 1	01:00	Hot tap water	N/A
Drying	15:00	90°C	N/A

10. Visibly inspect for remaining soil on part

#### Recommended Manual Cleaning Instructions:

1. Rinse with tap water to remove gross soil
2. Inject water (60mL) into cannulation to remove gross soil
3. Prepare enzymatic detergent (Enzol®) at manufacturer recommendation (1oz/gal) using lukewarm tap water and fully immerse parts
4. Use a soft bristled brush (Spectrum M16 or equivalent) and appropriately sized lumen brush to brush all surfaces
5. Use syringe to inject detergent (60mL) into cannulation
6. Allow articles to dwell in detergent bath for 1 minute
7. Remove parts from bath and rinse using reverse osmosis/deionized (RO/DI) water
8. Fill syringe with RO/DI water (60mL) and flush part cannulation, where applicable
9. Allow parts to air dry. A clean lint-free cloth may be used to aid in drying
10. Visibly inspect for remaining soil on part

#### NON-STERILE PRODUCT STERILIZATION

Trilliant Surgical Implant Systems can be packaged non-sterile and therefore must be sterilized prior to surgical use. Use of the sterilizer shall comply with the manufacturer's user instructions. The user facility must clean and disinfect instruments prior to sterilization per standard hospital procedures. Non-sterile devices are sterilizable by steam sterilization (autoclaving). The following parameters should be followed:

Sterilization Method	Pre-Vacuum Steam
Condition	Wrapped*
Temperature	270°F (132°C)
Time	4 minutes
Recommended Dry Time	30 minutes**

\* The system shall be packaged for sterilization by double wrapping in an FDA cleared wrap (i.e. Halyard® Sterilization Wrap) and wrapping techniques outlined per ANSI/AAMI ST79, then adhered with FDA cleared chemical indicator autoclave tape.

\*\* Trilliant Surgical has validated the recommended sterilization cycle and dry time for trays. The dry time varies due to load configuration, wrapping method, and material.

Note: Do not stack trays during sterilization.

This document is controlled by Trilliant Surgical. When downloaded, printed, and/or copied, this document becomes UNCONTROLLED and users should always check Trilliant Surgical's website, [www.trillianturgical.com](http://www.trillianturgical.com), to ensure they have the latest version.